


Adjust Software Setup Guide



Prerequisite:

- Running in Windows PC - From Windows 7
- Network card required
- Executable file (does not require installation).

Procedure:

- Unzip the file to a location of your choice
- Start the file Frenetik - Adjust_x.x.exe (x.x = 1.1 version)
- When the program is booting, the software will automatically scan your network. The visible speakers will appear in the drop-down menu
- Select the desired speaker and adjust the setting (level, bass, treble)
- To save your setting, click SAVE
- To adjust another speaker, select it in the drop-down menu
- Press SCAN to scan the network again and add the new speakers you may have connected while the software was running.

1	Speaker selection drop-down menu
2	SCAN button to manually scan your network (a scan is performed during booting)
3	SAVE button to save your speakers settings to your computer
4	RECALL button, to upload your setting from your computer
5	Bass and treble level adjustment button
6	Level adjustment Fader
7	Mute button, to mute/unmute the speaker

Adjust software is compatible with speaker models and batch numbers as follows:

- **Spik 3** : serial number from 01374000164 to 20121513741032
- **Spik 5** : serial number from 01527000001 to 01527000229
- **Spik 6** : serial number from 01426000001 to 01426000329
- **Spik Up** : serial number from 80523139800022 to 20120813980336
- **Spik Sub** : serial number from 01427000001 to 01427000089